



MOVING **INTELLIGENCE**

[www.movingintelligence.co.uk](http://www.movingintelligence.co.uk)

## Thank you for your purchase of one of our iTrack Secure 5 units

At the heart of our system is your Automatic Driver Recognition (ADR) tag. You should have 2 of these.

You should keep your ID tag separate from your vehicle keys, perhaps in a purse or wallet.

Once turned on you don't need to keep turning them on and off.



You'll notice the **little blue LED will flicker every 8 seconds**. This flicker will stop once the tag is stationary for 5 minutes. This helps battery life and ensures the signal cannot be detected or cloned. An internal kinetic sensor will restart the tag once its picked up.

**S5 tracking system**

## How does it work ?

The system works by automatically recognising the presence of one or both of the ADR tags. As the ignition turns on, if a tag cannot be detected the system is triggered sending an alert through to our 24 control room to contact you immediately.

If you have one of our ULTIMATE systems the vehicle will be immobilised at this point.

Indication that the tags have been recognised **is confirmed by 3 short beeps as the ignition turns on.**

The system re-arms automatically 30 seconds after the ignition turns off and a tag is no longer in range. **This is confirmed by 2 short beeps.**

## **Notes:**

Always keep your tags separate from the keys. This system is intended to protect you from theft of keys or cloned keys

Don't forget once the tags have been stationary for 5 minutes they stop transmitting. This prevents signal boosting or cloning when not in use and helps prolong battery life.

# **FAQ:**

## **Is my tag turned on ?**

Press the central button.

*If the LED lights up your tag is on*

## **How do I turn a tag off ?**

Press and hold the button for 10 seconds.  
If the tag is on, hold until the light blinks then release.

*Your tag will now be turned off.*

# FAQ:

## ***How do I turn a tag on ?***

If your tag is off the process is the same. Hold the button down, the light will remain off.

After 5 seconds the LED will blink.. Release the button.

***Your tag is now on.***

***Why can't I start my engine ?***

***Why do I get alerts when the tag is nearby ?***

***Has your tag gone into stand-by mode?***

***These are all likely the same issue.....***

***Your tag has gone to sleep. Simply shake the tag for 2 seconds to turn it back on.***

## More from us



[www.movingintelligence.co.uk](http://www.movingintelligence.co.uk)



# MOVING **INTELLIGENCE**

Moving Intelligence Ltd  
Trinity House  
Bredbury Park Way,  
Bredbury,  
Stockport  
SK6 2SN

t:0161 476 4050  
e:info@movingintelligence.co.uk

[www.movingintelligence.co.uk](http://www.movingintelligence.co.uk)